

Wood and Lucite Tzdakah Bank

Roz Hollander, Newton, New Jersey

Materials: Hard maple wood
2 Lucite sheets
Band saw
Sandpaper
12 pan head Phillips $\frac{3}{4}$ " to 1" screws
Optional: lacquer or wood stain*

Directions: 1. Cut the wood to the size of the bank
2. Cut the Lucite to size
3. Cut out the opening and the design from the wood
4. Sandpaper to a smooth finish
5. Stain the wood, if desired, at this point, and let it dry very well
6. Screw the Lucite to the wood

